

SOPHOS

Security made simple.

Sophos Central

Creating a guest network

Product Version 1.15
Sophos Limited 2017



Contents

- 1 About guest networks.....3
- 2 Creating a guest network.....4

1 About guest networks

Guest networks are networks which use the same access points as other networks but are configured to allow only access to the Internet.


2 Creating a guest network

About this task

You can either use an existing SSID or create a new SSID to enable a guest network. This guide describes how to set up a guest network with an existing SSID.

Procedure

1. Go to **SSIDs** and click the SSID for which you want to enable a guest network.
2. Go to **Advanced Settings > Client Connection**.



3. Choose the required connection type.

LAN	Bridges the client traffic into the same network the access point is connected to.
VLAN	Bridges the client traffic into a particular VLAN.

4. Click **Enable Guest Network**.
5. Choose the client addressing.

Bridge Mode	Filters all traffic and allows communication to the gateway, the DNS server and the external network.
--------------------	---

	Thereby you can add a guest network to an environment without VLAN and still have an isolation. Roaming between APs works flawlessly.
NAT Mode	Isolates every guest network on each access point.

6. Save your settings.
7. Provide the passphrase to guest network clients.